

MOULTRIE MOBILE™

EDGE

CELLULAR TRAIL CAMERA



QUICK START GUIDE

BEFORE YOU BEGIN

Download the Moultrie Mobile app to set up your camera, remotely control settings, view your pictures and videos, and more.



Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.
App Store is a service mark of Apple Inc. Google Play is a trademark of Google Inc.

TO GET STARTED, YOU'LL NEED:



**The Moultrie
Mobile App**



**Edge
Camera**



**8 or 16
AA Batteries**

Note: This camera has **built-in memory**. You do not need to purchase or install an SD card.

CAMERA SETUP

SEE HOW IT'S DONE

Scan the QR code to watch a video of the camera overview and step-by-step instructions for camera setup.



Need help?

Call Customer Success: 1-844-908-1219

1 ADD CAMERA TO ACCOUNT

- Download the Moultrie Mobile app, and log in or sign up for an account.
- For existing accounts, go to **DEVICES > ACTIVATE**.
- Scan the QR code on the camera (located inside control panel door).
- Select a monthly or annual plan.

2 INSTALL BATTERIES

- Press **EJECT** to release battery tray.
- Fill tray with either 8 or 16 AA batteries. (*Minimum of 8 required*)
- **If only using 8 batteries, completely fill one side.**


DO:

- Use recommended batteries:*
- Moultrie Alkaline
 - Energizer Alkaline
 - Energizer Lithium

DON'T:

- Use rechargeable batteries.
- Mix old and new batteries, or different brands.





3 TURN ON YOUR CAMERA

- Slide the power switch to **ON**. All LEDs will light up and then camera will connect.

	CONNECTING Flashes yellow as the camera connects.		CONNECTED Turns green upon successful connection.		NOT CONNECTED Turns red if connection is not found.
---	---	---	---	---	---

- *Camera activation and connection should take 5 minutes or less. If a firmware update is available after connection, LEDs will flash and the camera will power itself off and back on.*
- *If not connected, you may need to move your camera to a stronger signal area.*
- *All lights will turn off once the camera is on and connection attempt is complete.*

4 TEST YOUR CAMERA

- Once the camera is on and has connected, press the **CONNECT** button to trigger a test photo.
- When motion is detected, the battery LED will flash once for an image, or stay lit for a video.
- In the Moultrie Mobile app, go to **GALLERY**, then pull down to refresh and see your photo.

CAMERA PLACEMENT TIPS



- 1** Clear vegetation and tree limbs in the field of view to reduce false triggers.
- 2** Mount camera to a tree or pole approximately three to five (3-5) feet from ground.
- 3** Face the camera North or South to avoid over-exposure from the sun.
- 4** When scouting a game trail, angle the camera at a 45-degree angle to the trail for optimal triggering.

Visit MoultrieMobile.com for additional camera mounting options.

ADJUST CAMERA SETTINGS

You can view your camera's battery level and adjust settings remotely using the **Moultrie Mobile app**.

- Go to **DEVICES** to adjust settings and save changes.
- If you change settings from the app, the changes will be applied the next time the camera connects.
- To sync new settings faster, press **CONNECT** button on the camera to initiate a connection after updating settings in the app.

ACCESSORIES

Go to MoultrieMobile.com/accessories to purchase solar power products, camera mounts and other accessories.

MOULTRIE **MOBILE™**

CONNECT WITH US:   

MoultrieMobile.com

TROUBLESHOOTING

CAMERA WON'T CONNECT

If the red **NOT CONNECTED** light is on:

- Make sure camera has an **active** subscription with Moultrie Mobile.
- Move the camera to a location with a stronger signal.

COMPARING TO CELL PHONE SIGNAL

Your camera's signal strength may be higher or lower than your smartphone. Your camera is not tied to your cell phone plan. ***The Edge will automatically try to connect to the strongest network in your area.***

MANAGING IMAGES / MEMORY

- All pictures and downloads can be viewed and managed in the Moultrie Mobile app, even if they have been cleared from the camera's memory.
- **PRO TIP:** Request hi-res images and full video clips soon after they appear in your gallery, to avoid those files being deleted during onboard memory clean-up.

NEED HELP?

*For resources, troubleshooting,
and support, go to:*

Support.MoultrieMobile.com

Customer Success: 1-844-908-1219

WARRANTY



- This product has been thoroughly tested and inspected before shipment. ***It is guaranteed from defects in material and workmanship from the date of purchase for 2 years.***
- Under this limited guarantee, we agree to replace or repair free of charge any part or parts which have been found to be defective in original material or workmanship.
- Physical damage, abuse, misuse, alterations, or tampering with the equipment is not covered and will void your warranty.
- For more warranty information, visit:
MoultrieMobile.com/2022_MM_Warranty_Info
- Should you require warranty service, call our Customer Success Team: ***1-844-908-1219***

FCC Statements

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes and modifications not expressly approved by the party responsible could void the user's authority to operate this device. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.